


Point of Commencement
AMG Coordinates (Zone 56)
Easting 501820.936
Northing 6987332.693

See Appendix F for Metes and Bounds Description

—25— Existing Contours (1m interval)



TOWN CENTRE
FRAME

TOWN CENTRE
FRAME

Town Centre Frame 'R' Precinct
Town Centre Frame 'R' Sector Two

CADASTRAL BOUNDARIES

